



Pump Vault


20000, 60000, Extension

DE Gebrauchsanleitung
EN Operating instructions
FR Notice d'emploi
NL Gebruiksaanwijzing
ES Instrucciones de uso
PT Instruções de uso
IT Istruzioni d'uso
DA Brugsanvisning
NO Bruksanvisning
SV Bruksanvisning
FI Käyttöohje


HU Használati útmutató
PL Instrukcja użytkowania
CS Návod k použití
SK Návod na použitie
SL Navodila za uporabo
HR Uputa o upotrebi
RO Instrucțiuni de folosință
BG Упътване за употреба
UK Посібник з експлуатації
RU Руководство по эксплуатации
CN 使用说明书




Pump Vault 20000
(87096)



Pump Vault 60000
(89042)





Pump Vault Extension
(89043)



PVT0010





Pump Vault 20000



PVT0011




Pump Vault 60000



PVT0012

Pump Vault 20000




Aquarius Universal Premium 12000

Pump Vault 60000

Aquarius Eco Expert 28000




Pump Vault 20000



[mm]

Pump Vault 60000 + Extension




[mm]

PVT0013




Pump Vault 20000



PVT0014



Pump Vault 60000



PVT0015

OASE GmbH

Tecklenburger Straße 161
48477 Hörstel | Germany

📞 +49 (0) 5454 80-0

📠 +49 (0) 5454 80-9353

✉️ info@oase.com